eufy

SECURITY

Anker Innovations Limited. All rights reserved. **eufy Security and eufy Security Logo** are trademarks of Anker Innovations Limited, registered in the United States and other countries. All other trademarks are the property of their respective owners.


51005003059 V01

eufy
SECURITY

QUICK START GUIDE

eufy Security Video Doorbell Dual (Battery)

GUIDE DE DÉMARRAGE RAPIDE




English 01


Français 29

WHAT'S INCLUDED

For Video Doorbell Installation




eufy Security Video Doorbell Dual (Battery)
Model: T8213




Mounting Bracket




15° Mounting Wedge (Optional)




Screw Hole Positioning Card



Screw Pack



Extension Wires and Wire Nuts (Optional)



micro-USB charging cable



Detaching Pin




Quick Start Guide


For HomeBase 2 Installation



HomeBase 2
Model: T8010X



Power Adapter for
HomeBase 2




Ethernet Cable for
HomeBase 2

Note: Power plug may vary in different regions.

2 / PRODUCT OVERVIEW


Video Doorbell

Front View:



1. Motion Sensor
2. Microphone
3. Primary Camera Lens
4. Ambient Light Sensor
5. LED Ring / Doorbell Button
6. Secondary Camera Lens
7. Speaker


Rear View:



1. Detaching Mechanism
2. Micro USB Charging Port
3. SYNC/RESET Button
4. Power Terminals for Existing Doorbell Wires (Optional)

Operation	How-to
Power on the doorbell	Press the SYNC button.
Add doorbell to HomeBase	Press and hold the SYNC button until you hear a beep.
Power off the doorbell	Quick-press the SYNC button 5 times in 3 seconds.
Reset the doorbell	Press and hold the SYNC button for 10 seconds.

HomeBase 2




1. Status LED
2. Speaker
3. Power Port
4. USB Port
5. Ethernet Port
6. SYNC/ALARM OFF Button
7. Reset Button

3 / HOW THE SYSTEM WORKS

How the System Works

The video doorbell system includes 2 parts. One is the video doorbell at your door. The other is the HomeBase in your house.


The video doorbell detects motion at your porch and allows you to answer the door anytime and anywhere. The HomeBase stores video clips on its built-in storage. When someone rings the doorbell, people in the house will be notified.




4 / STEP 1
CONNECTING THE HOMEBASE

Connect HomeBase 2 to the Internet

1. Power on the HomeBase 2, then use the ethernet cable provided to connect the HomeBase 2 to your home router.



2. The LED indicator turns blue (this may take up to 1min) when HomeBase 2 is ready for setup.



5 / STEP 2
SETTING UP THE SYSTEM


Download the App and Set up the System


Download the eufy Security app from the App Store (iOS devices) or Google Play (Android devices).

Download on the App Store

GET IT ON Google Play

Sign up for a eufy Security account, then follow the onscreen instructions to complete the setup.






6 / STEP 3
DETERMINING THE POWER OPTION

Option 1 - Battery Powered


1. If you don't have existing doorbell wiring at the front door, use the built-in battery. You are free to determine the doorbell position and the mounting is easy and quick.
2. When the doorbell battery level is low, you need to detach and charge it.
3. If you choose this option, please jump to **STEP 4 FINDING A MOUNTING SPOT**.



Note: The battery life varies depending on usage. In most common cases, a doorbell may have up to 10 events per day and each recording lasts 20 seconds on average. Under this scenario, the doorbell battery life can last up to 6 months.

Option 2 - Doorbell Wire Powered

1. If you have existing and working doorbell wiring at the front door, the doorbell will be powered by the wires constantly. So you don't need to detach and charge it after installation.
2. Since the doorbell is connected to the wires, the mounting position is limited.
3. If you choose this option, please jump to **APPENDIX 3 POWERING THE DOORBELL WITH EXISTING DOORBELL WIRES**.



8 - 24V AC Doorbell Wiring


7 / STEP 4
FINDING A MOUNTING SPOT


Find a Mounting Spot

Take the video doorbell to your front door and check the live view on the app at the same time. Find a location where you can see the desired field of view.


Consider the following factors:

1. Check if you can reuse the existing holes and anchors on the wall or door frame.
2. If you want to place the doorbell close to a side wall, make sure the wall doesn't show up in the field of view. Otherwise IR light will be reflected and night vision will become blurry.
3. If you are drilling the mounting holes for the first time, the recommended mounting height is 48" / 1.2 m from the ground.
4. To adjust the angel, use the 15° mounting wedge as a supplementary mounting bracket.






Without 15° Mounting wedge



With 15° Mounting wedge

Place the screw hole positioning card against the wall to mark the position.





8 / STEP 5
MOUNTING THE BRACKET

Mount the Doorbell on a Wooden Surface


If you're mounting the doorbell on a wooden surface, you don't need to pre-drill pilot holes. Use the provided screws to secure the mounting bracket on the wall, the screw hole positioning card indicates the position of the screw holes.

What you need: Screwdriver, Mounting Bracket, 15° Mounting Wedge (Optional), Screw Packs





Without 15° Mounting Wedge





With 15° Mounting Wedge


Mount the Doorbell on Surfaces Made Out of Hard Materials

1. If you're mounting the doorbell on a surface made out of hard materials, like brick, concrete, stucco, drill 2 holes through the screw hold positioning card with a 15/64"(6mm) drill bit.
2. Insert the provided anchors, and then use the provided long screws to secure the mounting bracket on the wall.

What you need: Power Drill, 15/64"(6 mm) Drill Bit, Mounting Bracket, 15° Mounting Wedge (Optional), Screw Packs








Without 15° Mounting Wedge

2




With 15° Mounting Wedge

2

9 / STEP 6
MOUNTING THE DOORBELL

Mount the Doorbell

Align the doorbell on the bottom, and then move it into place on top. Press the doorbell down until it clicks.



You're all set!

If you want to detach the doorbell or recharge it, please refer to the following sections.


10 / APPENDIX 1
DETACHING THE DOORBELL

Detach the Doorbell

1. Use the doorbell detaching pin provided if you wish to detach the doorbell from the mounting bracket.
2. Press into the pinhole on top of the doorbell, and then lift the top for removal.


What you need: Doorbell Detaching Pin






11 APPENDIX 2
RECHARGING THE DOORBELL

Recharge the Doorbell






LED indicator	Charging: Flashing Green
	Fully charged: Green
Charging time	6 hours from 0% to 100%

12 / APPENDIX 3

POWERING THE DOORBELL WITH EXISTING DOORBELL WIRES

3.1 Verify whether the doorbell wires are working

1. Ring the existing doorbell to check if it is working. If the doorbell doesn't ring, your doorbell wires may be defective. Power the doorbell on its own battery or consult an electrician to fix the wires.
2. Shut off power at the breaker. Turn the lights on / off in your home to make sure the electricity in your house is properly shut off.




Always be careful when handling wires. If you're not comfortable installing it yourself, have a qualified electrician do it.


3.2 Detach the Existing Doorbell Button

If you already have existing doorbell wiring:

1. Remove the existing doorbell button with a Phillips-head screwdriver (not provided).
2. Pull the two wires out carefully when removing the existing doorbell. Straighten the wire ends if necessary.

What you need: Philips-Head Screwdriver






3.3 Find a Mounting Spot


1. When determining the mounting position of the doorbell, consider these factors:

   ① Check if you can reuse the existing holes and anchors on the wall or door frame.


   ② If you are drilling the mounting holes for the first time, the recommended mounting height is 48" / 1.2 m from the ground.

   ③ To adjust the angel, use the 15° mounting wedge as a supplementary mounting bracket.






Without 15° Mounting wedge



With 15° Mounting wedge


2. Place the screw hole positioning card against the wall to mark the position.




3.4 Mount the Bracket

If you're mounting the doorbell on a wooden surface, you don't need to pre-drill pilot holes. Use the provided screws to secure the mounting bracket on the wall. The screw hole positioning card indicates the position of the screw holes.

What you need: Power Drill, Mounting Bracket, 15° Mounting Wedge (Optional), Screw Packs





Without 15° Mounting Wedge


With 15° Mounting Wedge


If you're mounting the doorbell on a surface made out of hard materials, like brick, concrete, stucco:


① Drill 2 holes through the screw hole positioning card with 15/64"(6mm) drill bit.

② Insert the provided anchors, and then use the provided long screws to secure the mounting bracket on the wall.

What you need: Power Drill, 15/64"(6mm) Drill Bit, Mounting Bracket, 15° Mounting Wedge (Optional), Screw Packs








Without 15° Mounting Wedge

2




With 15° Mounting Wedge


2

3.5 Connect the Doorbell Wires to the Doorbell

Connect the wires to the terminals at the back of the doorbell, then tighten the terminal screws. Wire can connect to any terminal.

What you need: Wires and Wire Nuts (Optional), Video Doorbell, Philips-head Screwdriver






Note:

- To prevent short-circuiting, make sure the wires are not touching each other after connecting them to the terminals.
- If the wires are too short, use the extension wires and wire nuts provided to make them longer. Use electrical wiring tape instead if there is no more space on the wall for wire nuts.


3.6 Mount the Doorbell on the Bracket

Align the doorbell on the bottom, and then move it into place on top. Press the doorbell down until it clicks.



3.7 Restore Power

Switch the master circuit breaker back to ON.



You're all set!

If you want to detach the doorbell or recharge it, please refer to the corresponding sections.

13 / NOTICE

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition. The min separation distance is 20cm.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

The following importer is the responsible party
Company Name: POWER MOBILE LIFE, LLC
Address: 10900 NE 8TH ST, STE 501, BELLEVUE, WA 98004
Telephone: 1-800-988-7973

IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device."

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil nedoit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.


IC RF Statement:

When using the product, maintain a distance of 20cm from the body to ensure compliance with RF exposure requirements.


Lors de l'utilisation du produit, maintenez une distance de 20 cm du corps afin de vous conformer aux exigences en matière d'exposition RF.

COMPOSANTS INCLUS
INCLUS

Pour installation de la sonnette vidéo




eufy Security Video Doorbell Dual (Battery)
Modèle : T8213




Support de montage




Cale de montage 15° (facultatif)




Trou de vis Carte de positionnement



Jeu de vis



Fils d'extension et écrous de fil (facultatif)



Câble de charge micro-USB



Épingle de détachement




GUIDE DE DÉMARRAGE RAPIDE


Pour l'installation du HomeBase 2



HomeBase 2
Modèle : T8010X



Adaptateur d'alimentation pour HomeBase 2




Câble Ethernet pour HomeBase 2

Remarque : la prise de l'adaptateur d'alimentation peut varier selon les régions.

2 / PRODUIT
APERÇU


Sonnette vidéo

Vue de face :



1.Détecteur de mouvement
2.Microphone
3.Objectif principal de la caméra
4.Détecteur de lumière ambiante
5.Anneau LED / Bouton de sonnette
6.Objectif secondaire de la caméra
7.Haut-parleur


Vue arrière :



1.Mécanisme de détachement
2.Port de charge micro-USB
3.Bouton SYNC/RESET
4.Bornes d'alimentation pour fils de sonnette existants (en option)

Fonctionnement	Instructions
Mise en marche de la sonnette	Appuyez sur le bouton SYNC.
Ajouter la sonnette à la station HomeBase	Appuyez sur le bouton SYNC et maintenez-le enfoncé jusqu'à ce que vous entendiez un bip.
Mettre la sonnette hors tension	Appuyez rapidement sur le bouton SYNC 5 fois en 3 secondes.
Réinitialiser la sonnette	Appuyez sur le bouton SYNC pendant 10 secondes

HomeBase 2




1.LED d'état
2.Haut-parleur
3.Port d'alimentation
4.Port USB
5.Port Ethernet
6.Bouton SYNC/ALARM OFF
7.Bouton de réinitialisation

3 / DU SYSTÈME FONCTIONNEMENT

Fonctionnement du système

Le système de sonnette vidéo comprend 2 parties.La première est la sonnette vidéo à votre porte.L'autre est le module HomeBase dans votre maison.


La sonnette vidéo détecte les mouvements sur votre porche et vous permet de répondre à la porte à tout moment et depuis n'importe où.Le module HomeBase stocke les clips vidéo sur son système de stockage intégré.Lorsque quelqu'un sonne à la porte, les personnes présentes dans la maison sont averties.




4 / ÉTAPE 1
CONNEXION DU MODULE HOMEBASE

Connexion du module HomeBase 2 à Internet

1. Mettez le HomeBase 2 sous tension, puis utilisez le câble Ethernet fourni pour brancher le HomeBase 2 au routeur de votre domicile.



2. L'indicateur LED devient bleu (cela peut prendre une minute) lorsque HomeBase 2 est prêt à être configuré.



5 / ÉTAPE 2
Configuration du système


Téléchargement de l’application et configuration du système


Téléchargez l'application eufy Security depuis l'App Store (appareils iOS) ou Google Play (appareils Android).

Download on the App Store

GET IT ON Google Play

Créez un compte eufy Security, puis suivez les instructions à l’écran pour terminer la configuration.






6 / ÉTAPE 3
DÉTERMINATION DE L'OPTION D'ALIMENTATION

Option 1 - Alimentation par batterie


1. Si vous n'avez pas de câblage de sonnette à la porte d'entrée, utilisez la batterie intégrée.Vous êtes libre de déterminer la position de la sonnette et le montage est simple et rapide.
2. Lorsque le niveau de la batterie de la sonnette est faible, vous devez la détacher et la charger.
3. Si vous choisissez cette option, passez à l'ÉTAPE 4 RECHERCHE D'UN EMPLACEMENT DE MONTAGE.



Remarque : la durée de vie de la batterie varie en fonction de l'utilisation. Dans la plupart des cas, une sonnette peut avoir jusqu'à 10 événements par jour et chaque enregistrement dure en moyenne 20 secondes.Dans ce cas de figure, la durée de vie de la batterie de la sonnette peut aller jusqu'à six mois.

Option 2 - Alimentation par câblage de sonnette

1. Si vous avez un câblage de sonnette existant et fonctionnel à la porte d'entrée, la sonnette sera alimentée en permanence par celui-ci. Vous n'avez donc pas besoin de la détacher et de la charger après l'installation.
2. Étant donné que la sonnette est connectée aux fils, la position de montage est limitée.
3. Si vous choisissez cette option, passez à l'ANNEXE 3 ALIMENTATION DE LA SONNERIE AVEC LES FILS DE SONNERIE EXISTANTS.



Câblage de sonnette 8 à 24 V C.A.


7 / ÉTAPE 4
RECHERCHE D'UN POINT DE MONTAGE


Recherche d'un point de montage

En amenant la sonnette vidéo à la porte d'entrée, consultez l'affichage en direct sur l'application.Recherchez un emplacement qui vous offre le champ de vision souhaité.


Tenez compte des facteurs suivants :

1. Vérifiez si vous pouvez réutiliser les trous et les ancrages existants sur le mur ou le cadre de la porte.
2. Si vous souhaitez placer la sonnette à proximité d'un mur latéral, assurez-vous que le mur n'apparaît pas dans le champ de vision.Sinon, la lumière infrarouge sera réfléchie et la vision nocturne deviendra floue.
3. Si vous percez les trous de montage pour la première fois, la hauteur de montage recommandée est de 1,2 m du sol.
4. Pour ajuster l'ange, utilisez la cale de montage de 15° comme support de montage supplémentaire.






sans cale de montage à 15°



avec cale de montage à 15°

Placez la carte de positionnement des trous de vis contre le mur pour marquer la position.





8 / ÉTAPE 5
MONTAGE DU SUPPORT

Montage de la sonnette sur une surface en bois


Si vous montez la sonnette sur une surface en bois, vous n'avez pas besoin de percer d'avant-trous.Utilisez les vis fournies pour fixer le support de montage au mur. La carte de positionnement indique la position des trous de vis.

Éléments requis : Tournevis, support de montage, cale de montage 15° (en option), jeux de vis





Sans cale de montage 15°





Avec cale de montage 15°


Monter la sonnette sur des surfaces en matériaux durs

1. Si vous montez la sonnette sur une surface en matériaux durs, comme la brique, le béton ou le stuc, percez 2 trous à travers la carte de positionnement des vis à l'aide d'un foret de 15/64" (6 mm).
2. Insérez les chevilles fournies, puis utilisez les longues vis fournies pour fixer le support de montage au mur.

Éléments requis : Perceuse électrique, foret 15/64" (6 mm), support de montage, cale de montage 15° (en option), jeux de vis








Sans cale de montage 15°

2




Avec cale de montage 15°

2

9 / ÉTAPE 6
MONTAGE DE LA SONNERIE

Montage de la sonnette

Alignez la sonnette en bas, puis placez-la en haut.Appuyez sur la sonnette jusqu'à ce qu'elle s'enclenche.



Le montage est terminé.


Si vous souhaitez détacher la sonnette ou la recharger, veuillez vous reporter aux sections suivantes.


10 / ANNEXE I
DÉTACHEMENT DE LA SONNETTE

Détachement de la sonnette

1. Utilisez la goupille d'éjection de sonnette fournie si vous souhaitez retirer la sonnette du support de montage.
2. Appuyez dans le trou d’épingle sur le dessus de la sonnette, puis soulevez la partie supérieure pour la retirer.


Éléments requis : Goupille de détachement de sonnette






11 / ANNEXE 2
RECHARGE DE LA SONNERIE

Recharge de la sonnette






Voyant LED	Chargement :Vert clignotant
	Chargement terminé :Vert
Temps de charge	6 heures de 0 % à 100 %

12 / ANNEXE 3

ALIMENTATION DE LA SONNERIE AVEC LES FILS DE SONNERIE EXISTANTS

3.1 Vérification du fonctionnement des fils de la sonnette

1. Testez la sonnette existante pour vérifier qu'elle fonctionne.Si la sonnette ne sonne pas, les fils de votre sonnette sont peut-être défectueux.Alimentez la sonnette sur sa propre batterie ou consultez un électricien pour réparer les fils.
2. Coupez le courant au disjoncteur.Allumez/éteignez les lumières de votre maison pour vous assurer que l'électricité est bien coupée.




Soyez toujours prudent lorsque vous manipulez des fils électriques. Si vous n'êtes pas à l'aise pour l'installer vous-même, faites appel à un électricien qualifié.


3.2 Détacher le bouton de sonnette existant

Si vous avez déjà un câblage de sonnette existant :

1. Retirez le bouton de sonnette existant à l'aide d'un tournevis cruciforme (non fourni).
2. Tirez les deux fils avec précaution lors du retrait de la sonnette existante. Redressez les extrémités des fils si nécessaire.

Éléments requis : Tournevis à tête cruciforme






3.3 Trouver un emplacement de montage


1. Lorsque vous déterminez la position de montage de la sonnette, tenez compte des facteurs suivants :

   ① Vérifiez si vous pouvez réutiliser les trous et les ancrages existants sur le mur ou le cadre de la porte.


   ② Si vous percez les trous de montage pour la première fois, la hauteur de montage recommandée est de 1,2 m du sol.

   ③ Pour ajuster l'ange, utilisez la cale de montage de 15° comme support de montage supplémentaire.






sans cale de montage à 15°



avec cale de montage à 15°


2. Placez la carte de positionnement des trous de vis contre le mur pour marquer la position.




3.4 Montage du support


Si vous montez la sonnette sur une surface en bois, vous n'avez pas besoin de percer d'avant-trous.Utilisez les vis fournies pour fixer le support de montage au mur.La carte de positionnement des trous de vis indique la position des trous de vis.

Éléments requis : Perceuse électrique, support de montage, cale de montage 15° (en option), jeux de vis





Sans cale de montage 15°




Avec cale de montage 15°


Si vous montez la sonnette sur une surface en matériaux durs, comme de la brique, du béton ou du stuc :


① Percez 2 trous à travers la carte de positionnement des trous de vis avec un foret de 15/64" (6 mm).

② Insérez les chevilles fournies, puis utilisez les longues vis fournies pour fixer le support de montage au mur.

Éléments requis : Perceuse électrique, foret 15/64" (6 mm), support de montage, cale de montage 15° (en option), jeux de vis








Sans cale de montage 15°

2




Avec cale de montage 15°


2

3.5 Connecter les fils à la sonnette

Connectez les fils aux bornes situées au dos de la sonnette, puis serrez les vis des bornes.Les fils peuvent être connectés à n'importe quelle borne.

Éléments requis : Fils et écrous (en option), sonnette vidéo, tournevis cruciforme






Remarque :

- Pour éviter les courts-circuits, assurez-vous que les fils ne se touchent pas après les avoir connectés aux bornes.
- Si les fils sont trop courts, utilisez les fils d'extension et les écrous fournis pour les rallonger.Utilisez du ruban de câblage électrique à la place s'il n'y a plus d'espace sur le mur pour les écrous de fil.


3.6 Montage de la sonnette sur le support

Alignez la sonnette en bas, puis placez-la en haut.Appuyez sur la sonnette jusqu'à ce qu'elle s'enclenche.



3.7 Rétablir le courant

Remettez le disjoncteur principal sur MARCHE.



Le montage est terminé.

Si vous souhaitez détacher la sonnette ou la recharger, veuillez vous reporter aux sections correspondantes.

Customer Service

Service client

Warranty
Garantie

12-month limited warranty
Garantie limitée de 12 mois

Call Us
Par téléphone

United States	+1 (800) 988 7973	Mon-Fri 9AM-5PM (PT)
United Kingdom	+44 (0) 1604 936 200	Mon-Fri 6AM-11AM (GMT)
Germany	+49 (0) 69 9579 7960	Mon-Fri 6:00-11:00

Email Us
Par e-mail

Customer Support: support@eufylife.com

Anker Innovations Limited
Room 1318-19, Hollywood Plaza, 610 Nathan Road, Mongkok, Kowloon, Hong Kong

@EufyOfficial @EufyOfficial @EufyOfficial